

Quick Start Guide

HPS-01

Please read carefully the instruction manual before use. Contents of this manual are subject to change without prior notice for reasons such as functionality enhancements.

Package







HPS-01 Bracket

Quick Start Guide

<u>Features</u>

- 1 input 2 output design (Possible to connect 2 network devices using 1 cable)
- Extended Ethernet transmission distance up to 200m (Configured with the Hybrid PoE Switch Series)
- 10/100 Base-T Ethernet (Full Duplex)
- Power Status LED indication
- PoE input
- DC48~57V power input
- · Cascade configuration
- Over current protection for secured power supply
- Surge Protection

Installation Guide


1. Product Image








- 2. HPS-01 is powered by power supply or PSE (Power Sourcing Equipment) such as PoE Switch or Injector.
- 3. Connect UTP cable from PSE to "PoE \mbox{IN} " port. Data/PoE LED indicates working status.



4. Connect UTP cable from Camera to "PoE OUT" port and Data/PoE LED indicates working status. Also, applying additional HPS-01s on the one of "PoE OUT" port, it is possible to connect multiple network devices in a cascade configuration.




LED Indicators

Indicator	Color	Function
DATA		Blinking : Ethernet Data Act
PoE		ON : PoE Powered
PWR/RUN	•	Normal (48VDC and more)
	•	Caution
	•	Power Shortage (38VDC and below)

Applications

57V DC/1.2A Power Supply (optional)



Transmission distance may vary depending on the type and quality of cable.

Specification

Model		HPS-01: 2 Port Hybrid PoE Switch
Interface	Downlink	2 x RJ-45
	Uplink	1 x RJ-45 - 10/100 Base-T with Auto-detect MDIX
Transmission Rate		100 Mbps Full Duplex
Transmission distance	Ethernet / PoE	Up to 100m - 1000 Base-T Up to 200m between devices - 10/100 Base-T
LED Indication	Data	3 x Data Link (Green)
	PoE	3 x PoE Link (Amber)
	PWR	1 x Input Power Quality (Green: Normal/48VDC and more, Green+Red: Caution, Red: Power Shortage/38VDC and below
Power Input	PoE	IEEE802.3af, IEEE802.3at
	DC	DC48V ~ 57V
Power Output	PoE	IEEE802.3af, IEEE802.3at
Mechanical	Dimension	80.4(L) x 61.6(W) x 24(H) mm
	Weight	102g
Environment	Operating Temp.	- 20 ~ 60 °C
	Storage Temp.	- 30 ~ 80 ℃
	Relative Humidity	10% ~ 90%
Compliance	Certification	FCC, CE, KC, RoHS
	Surge Protection	IEC 61000-4-5 4kV(1.2 / 50us), 2kV(8 / 20us)
Optional Accessories		57VDC / 1.2A External Power Supply

Caution

- Please install the device following the installation guide.
- Do not touch the device and cable with wet hands.
- Keep away from moisture and shock.
- Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus that produce heat.
- Indoor use only.
 Do not use for other purposes.
- Do not disassemble or modify this device. Do not put any sticker or paint on it.
- If this device is defective or malfunctioning, please unplug the power adapter immediately and contact dealer or service center.

Warranty

- This device has passed the quality control and product inspection. Please install and use according to the installation guide. The warranty period for this product is 24 months from the date of purchase.
- If this device is defective or malfunctioning, please unplug the power adapter immediately and contact dealer or service center.
- Any damages or breakage from user's abuse, accident, modification or natural disasters will not be covered manufacturer's warranty.





Please visit below website for more detailed information.

Tel: 031 365 3133~4 Web: http://www.intercoax.com E-mail: info@intercoax.com Fax: 031, 365, 3135

This device complies with part 15 of the fcc rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and

(2) This device must accept any interference received including interference that may cause undesired operation